

Step 1 - Install the laces to the desired loop hole, leave approximately 2cm & trim with sharp

Step 2 - Carefully singe the ends with a lighter, then align the metal cap to the end of

Step 3 - Press down firmly until you hear a click to ensure the locking mechanism is

Step 4 - Now slip on your shoes & never stress about tying your shoes again!



[SEE COLLECTION](#)